

# Size chart bridle

All measurements are listed in CM.

## Bridle Eris

	Cob	Full
A1	43	47
A2	53	57
B	40	42
C1	69	75
C2	76	84
D1	3	3
D2	4	4
E	38	38

A1 = Top of the head to bit (single side): shortest position

A2 = Top of the head to bit (single side): longest position

B = Length browband (measured straight across)

C1 = Circumference noseband: shortest position

C2 = Circumference noseband: longest position

D1 = Width noseband excluding padding

D2 = Width noseband including padding

E = Length flash strap in longest position

