

# Size chart bridle

All measurements are listed in CM.

## Bridle Sensisoft

	Cob	Full
A1	46	50
A2	56	61
B	43	46
C1	54	60
C2	68	71
D1	2	2
D2	6	6
E	57	57

A1 = Top of the head to bit (single side): shortest position

A2 = Top of the head to bit (single side): longest position

B = Length browband (measured straight across)

C1 = Circumference noseband: shortest position

C2 = Circumference noseband: longest position

D1 = Width noseband excluding padding

D2 = Width noseband including padding

E = Length flash strap in longest position

